Installation Instructions:

Check and comply with local building codes.

DIRECTIONS FOR VENTING A RANGE HOOD OR MICROWAVE OVEN

Before starting, plan the installation and read all instructions.

If the range hood or microwave oven is equipped with a round exhaust outlet, turn the adjustable elbow to 900 and connect to the outlet using the non-crimped end. Secure using supplied duct tape.

If the range hood or microwave oven has a 3 ¼" x 10" exhaust outlet, start the installation by attaching the 3 ¼" x 10" to 7" round transition supplied to the rectangular outlet on the range hood or microwave oven. Turn adjustable elbow to 900 and connect the non-crimped end to the crimped end of the transition. Secure using supplied duct tape.

Snap the length of pipe together. Cut a 7 ½" round hole in the wall where the pipe will pass through the outside wall. Note: Avoid beams and electrical connections.

Pass the non-crimped end of the pipe through the wall from the exterior. If the distance from elbow to the outside wall is less than length of pipe, cut the pipe to the desired length from the non-crimped side.

Connect the non-crimped end of the pipe to the elbow previously installed. Secure using supplied duct tape.

From outside wall, take the louvered vent and place crimped end of pipe into louvered vent collar. Secure using supplied duct tape.

Secure louvered vent to the outside wall using 4 screws (Not Included). Caulk around the vent and outside wall if necessary.

Note: Check the range hood or microwave oven manufacturer's warranty for compliance.



